

TECHNICAL DRAWING

PHOTO



PRODUCT FAMILY: ACCESSORIES FOR COMMUNITY

CODE: MP542N

DESCRIPTION:

Manual liquid soap or sanitizer gel dispenser

APPROVALS/CERTIFICATIONS:

TUV certification UNI EN ISO 900

PRODUCT FEATURES:

Manual liquid soap or sanitizer gel dispenser. With a wide window for the control of the level of product. Capacity 1.2 liters. Stainless steel. Screws for wall mounting included. Dimensions 110 x 110 x 330 mm.

ST_PRODOTTO: M542N - 1	APPROVATO R.T.
REV.02 DEL 08/02/2023	

The above mentioned information cannot be considered as binding. Thermomat Saniline S.r.l. reserves the right to make technical and aesthetic changes without any prior notice.

Thermomat Saniline s.r.l.

Via M. Curie, 7 - 46034 Borgo Virgilio (Mantova) ITALY

Tel. + 39 0376 4473

www.thermomat.com - info@thermomat.com



Company with Quality Management System certified according to the standard UNI EN ISO 9001:2015

FIXING/INSTALLATION:

Fix to the wall using the screws included.

MAINTENANCE:

Clean with soft damp cloth or mild detergent.

Do not use chlorine or its derivatives.

CLEAN THE PRODUCT INSIDE: Most of the problems of a soap dispenser are due

to the agent used. Very concentrated soaps cause blockages in the pumps, and

excessively liquid or diluted soaps have insufficient viscosity and tend to flow too

easily. Another general problem rescontrated on the dispensers is the use of

products very acid or very basic. Soaps very acid (pH 8,5) can cause serious

damages to plastic components and skin irritations.

Our dispensers are designed in order to be used with sopas with neutral PH. Also

the lack of maintenance and cleaning can be the cause of additional problems. If you

don't use the product for a long period, there is the risk of blockage. It will be

necessary in this case to clean the dispenser by emptying the tank and filling it with

hot water. Once done, the water will be pumped by activating the dispener. in case of

serious obstructions, it will be necessary to make a special cleaning. Remove the

dispenser from the wall, if possible. The tank must be empty, also the pump. Every

element has to be immersed in hot water for 30 minutes. After that, during the

immersion, use the pump of the dispenser. The water will help to clean in case of

soap elements. Dry the elements with a soft cloth and install them.

PRODUCT COMPOSITION:

N° 1 - Liquid soap Dispenser - aisi 304 Stainless steel

PACKAGING OF THE PRODUCT:

Individually packed in a cardboard box 105 x 120 x 332 mm.

Weight: 1,5 kg

ST_PRODOTTO: M542N - 1	APPROVATO R.T.
REV.02 DEL 08/02/2023	

The above mentioned information cannot be considered as binding. Thermomat Saniline S.r.l. reserves the right to make technical and aesthetic changes without any prior notice.

Thermomat Saniline s.r.l.

Via M. Curie, 7 - 46034 Borgo Virgilio (Mantova) ITALY

Tel. + 39 0376 4473

www.thermomat.com - info@thermomat.com



Company with Quality Management System certified according to the standard UNI EN ISO 9001:2015